

## Installation Guide: Rail Timer (TRT7W)

Thank you for choosing the Thermorail TRT7W Timer. As a commitment to efficiency, the environment and to save costs, the TRT7W can save you considerable money each year while still giving you the benefits of a warm, dry towel when you need it

### Installation Procedure:

#### Do

- Mount the timer at eye level
- Read the instructions fully so as to get the best from your timer
- Get the timer installed by a qualified electrician

#### Don't

- Do not install near a direct heat source as this will affect functionality
- Do not push hard on the screen as this may cause irreparable damage

#### Step 1

Carefully separate the front half of the timer from the back plate by removing the screw on the bottom face and disconnecting the ribbon cable.

#### Step 2

Place the timer front somewhere safe  
Terminate the timer as shown in the diagram shown.

#### Step 3


Screw the timer back plate securely into back box or directly to the wall or panel

#### Step 4

Reconnect the ribbon cable and replace the front plate onto the back plate securing it in place with the retaining screw.  
Power can now be switched on and your are ready for programming

### Getting To Know your Timer:

1. Day Indicator, displays the days of the week
2. Set – displayed when changes are been made
3. Program Indicator – displayed during programming
4. Main Menu – displays which option is currently Selected
5. Holiday left – Displayed when the timer is in holiday mode
6. Hold left – displayed when the temperature hold feature is activated, the remaining time will be shown
7. Timer Status – Displays the current status of timer
8. Keypad Lock Symbol – displayed when keypad is locked



## Installation Guide: Rail Timer (TRT7W)

### Programming:

**Now you need to program the current day and time.** This is done as follows

1. Use the left/right keys to scroll to clock and press the tick button.....√
2. Use the up/down buttons to select hours (24 hour format) and press tick to confirm.....√
3. Use the up down buttons to select minutes and press tick to confirm.....√
4. Use right/left buttons to select day, press the tick button to confirm and return to main menu.....√

**You now need to choose the best program option from the following selection.**

- You have the 4 programming options
1. Monday to Friday the same and weekends different
  2. All 7 days different
  3. All seven days the same
  4. Simply use it as a countdown timer (30 mins to 24 hours)

Selection of your preferred option is simple

1. Use the left/right keys to scroll to Setup and press the tick key.....√
2. Select 1 -3 as above and press the tick key.....√

Now you need to program the on/off times (we suggest you allow 1 hour for the rail to warm up your towels before you need them)

**To program the on/off times,** follow these easy steps

1. Use the left/right keys to scroll to edit and press the tick key.....√
2. Use the left/right keys to select the day/period of the week, press the tick to confirm.....√
3. 1 will now flash and the current on time will be displayed, the off time can be viewed by pushing the down key.
4. Select an on switching time and push the tick key to confirm.....√
5. Use the up/down buttons to select an off switching time and push the tick key to confirm.....√
6. 2 Will now flash and the 2<sup>nd</sup> on time will be display, repeat steps 4 and 5 to select and push the tick key to confirm your selection.....√
7. Repeat the steps for all set periods. For any unused periods enter -:-.
8. When selection complete, use the < > keys to scroll to DONE and press the tick key to confirm your selection.....√

### Additional Options:

If you wish to switch the timer off for an extended period simply scroll with the < > keys to the off button and push the tick key. (All programming will be stored in Memory). To switch back on simply push the tick key.

Holiday mode: if you are going away for a period you can select holiday mode. Scroll with the < > keys to Holiday and hold for 10 seconds. Select the number of days you will be away, and push the tick key. The timer will switch back on after the selected number of days.

Locking the Keypad: you can lock the keypad to prevent anyone from changing your settings. Simple hold the tick key for 10 seconds. The display will show 00:00 and you will need to enter a 4 digit code, select the first 2 digits and then push the tick key and then select the 2<sup>nd</sup> 2 digits. Then press the tick key to confirm. The lock symbol will show on the screen. To unlock simply reverse the procedure.

## Installation Guide: Rail Timer (TRT7W)

### Warranty:

Thermogroup covers all its products with a satisfaction guarantee. In addition Thermogroup will supply a replacement product where a fault is shown to be caused by manufacture, materials or workmanship providing the goods have been installed correctly and according to installation instructions. This guarantee does not include removal, freight or installation costs. Thermogroup's products come with guarantees that cannot be excluded under Australian Consumer Law and you are entitled to a replacement or refund for a major failure & compensation for any other reasonable foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

All of the standard Timers have a 1 year warranty. To use the warranty, repair or service the customer must provide purchase invoice/receipt, and any other relevant details.

If the product develops a fault within the warranty period due to normal wear and tear, Ablaze mirrors at its discretion will recognise whether it's a faulty product or not. If it is impossible or not economical for the manufacturer to repair the product, the manufacturer will replace the faulty product with a new unit of the same model or if there is no stock available of the same model as the product, the manufacturer will replace the product with a new unit of a similar size. No responsibility can be taken for altered dimensions and lining up of existing holes.

The repair service offered within the warranty period only covers the faults and problem as developed from the manufacturer's errors. Any damage caused by improper use or carelessness or incorrect wiring is not covered.

Ablaze Mirrors is not responsible for any monetary loss or injuries caused by improper use of this product.

#### CONTACT US ONLINE



Browse our full product range, watch videos, download product literature and get a quote, all on the Thermogroup website.

[www.thermogroup.com.au](http://www.thermogroup.com.au)

#### CONTACT US BY PHONE



Got a question or query?  
Call our AUS support line free from your land line. Open 07:30 – 16:30 Mon – Fri

**1300 368 631**

#### CONTACT US BY MAIL



Tell your satnav where to find us or just write us a letter to say hello!

**Thermogroup Pty Ltd, 28-30  
Pine Ave, Leeton, NSW 2705**

**Thermogroup**au

Thermogroup Pty Ltd  
PO Box 822  
LEETON NSW 2705  
Tel: 1300 368 631  
Fax: 1300 655 532  
[sales@thermogroup.com.au](mailto:sales@thermogroup.com.au)  
[www.thermogroup.com.au](http://www.thermogroup.com.au)  
© Thermogroupau 2014