

Installation Guide: Rail Timer (TRTS)

Thank you for choosing the Thermorail TRTS Timer. As a commitment to efficiency, the environment and to save costs, the TRTS can save you considerable money each year while still giving you the benefits of a warm, dry towel when you need it.

Installation Procedure:

Do

- Mount the timer at eye level
- Read the instructions fully so as to get the best from your timer
- Get the timer installed by a qualified electrician

Don't


- Do not install near a direct heat source as this will affect functionality
- Do not push hard on the screen as this may cause irreparable damage



Installation and wiring:

Carefully separate the front half of the timer from the back plate by placing a small flat head terminal driver into the slots on the bottom face of the timer.

Carefully unplug the ribbon connector which is plugged in to the front half of the timer. Place the timer front half somewhere safe. Terminate the timer as shown in the diagrams. Screw the timer back plate on selected wall plate. Re-connect the timer ribbon cable and clip the two halves together.



Configuration Menu:

Step 1

Turn the timer on by pressing. **POWER**

Step 2

Press **MENU** you will then see menu 01.

Step 3

Use the up and down arrows to adjust the clock format.

Step 4

Press **NEXT** to move to the next Menu and once you have all the menu options set,

Step 5

Press **DONE** to accept and store.

Setting the Clock & Day of week:

This timer is fitted with a time clock. It is essential that the clock and day are set accurately in order for the timer to operate effectively.

Step 1

Touch the time display and the time will start flashing. Use the up and down arrows to set the time. By holding the arrow down the time will change faster.

Step 2

Press **NEXT** to move to the Day setting and use the up and down arrows to get to the correct day.

Step 3

Press **DONE** to store and exit

Menu #	Feature	Explanation	Adjustment
01	Clock Format	You can select the clock to show in either 12 or 24 hour time	24 hr is the default
02	5 + 2/ 7 Day Mode	This allows you to program either 5 days at once, then the weekend separately, or a full 7 days at the same time or 7 days separately	01 = 5 + 2 Day programmable 02 = 7 Day programmable

Installation Guide: Rail Timer (TRTS)

Setting time Schedules:

This timer has the ability to program each individual day of the week separately, or program 7 days of the week at once. You can also program weekdays (5 Days) to one schedule and then weekends (2 days) to a different schedule.

Program	Start Time	Status
1	07:00	ON
2	09:30	OFF
3	16:30	ON
4	22:30	OFF

Step 1

Press **SCHEDULE** and the day display will start flashing. (If your timer is set to 5+2 day programmable mode, then skip to step 3)

Step 2

Use the  to adjust the day of the week you want to start programming or to the day you wish to edit an existing event / program. (Press **ALL DAYS** to select all 7 days of the week, and to cancel press **ALL DAYS** again.)

Step 3

Press **ALL DAYS** the LCD screen will show program 1 and the time will be flashing

Step 4

Use  and  to adjust the time you wish the Program 1 () event to commence for the selected day/days.

Step 5

Press **NEXT** and the ON or OFF status will start flashing.

Step 6

Use  and  to set the desired status to be maintained during Program 1.

Step 7

Press **NEXT** and the LCD screen will show Program 2 with the time display flashing, this signifies that the second daily event is now ready to be programmed.

Repeat steps 4,5,6 to set the remaining programs/events, then press **DONE** to store and exit.

Hint: During setting programs, press **DELETE** which will clear a program entry and the timer will maintain the status of the last executed program until the beginning of the next program.

Auto / Manual mode:

Press **MODE** to select Auto / Annual mode. In Manual mode (), the timer will have to be manually turned on and off. First touch the ON or OFF display. And you the up and down arrows to select the desire function. In Auto mode, the timer operates automatically within the set time schedules.

Lock the Keypad:

To look the keypad, press and hold the top left corner for 5 seconds, you will see a lock symbol (). To unlock the timer press the top left corner again and the lock symbol will disappear.

Reset to Factory Setting:

With the timer turned off, press and hold for 5 seconds until you see --- : --- on the screen

Installation Guide: Rail Timer (TRTS)

Warranty:

Thermogroup covers all its products with a satisfaction guarantee. In addition Thermogroup will supply a replacement product where a fault is shown to be caused by manufacture, materials or workmanship providing the goods have been installed correctly and according to installation instructions. This guarantee does not include removal, freight or installation costs. Thermogroup's products come with guarantees that cannot be excluded under Australian Consumer Law and you are entitled to a replacement or refund for a major failure & compensation for any other reasonable foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

All of the standard Timers have a 1 year warranty. To use the warranty, repair or service the customer must provide purchase invoice/receipt, and any other relevant details.

If the product develops a fault within the warranty period due to normal wear and tear, Ablaze mirrors at its discretion will recognise whether it's a faulty product or not. If it is impossible or not economical for the manufacturer to repair the product, the manufacturer will replace the faulty product with a new unit of the same model or if there is no stock available of the same model as the product, the manufacturer will replace the product with a new unit of a similar size. No responsibility can be taken for altered dimensions and lining up of existing holes.

The repair service offered within the warranty period only covers the faults and problem as developed from the manufacturer's errors. Any damage caused by improper use or carelessness or incorrect wiring is not covered.

Thermogroup is not responsible for any monetary loss or injuries caused by improper use of this product.

CONTACT US ONLINE



Browse our full product range, watch videos, download product literature and get a quote, all on the Thermogroup website.

www.thermogroup.com.au

CONTACT US BY PHONE



Got a question or query?
Call our AUS support line free from your land line. Open 07:30 – 16:30 Mon - Fri

1300 368 631

CONTACT US BY MAIL



Tell your satnav where to find us or just write us a letter to say hello!

**Thermogroup Pty Ltd, 28-30
Pine Ave, Leeton, NSW 2705**

Thermogroupau

Thermogroup Pty Ltd
PO Box 822
LEETON NSW 2705
Tel: 1300 368 631
Fax: 1300 655 532
sales@thermogroup.com.au
www.thermogroup.com.au
© Thermogroupau 2014