# **Ablaze Back-Lit Mirrors**

Premium Range Back-Lit Mirrors


Installation Guide



## Contents

| Installation              | 4 |
|---------------------------|---|
| Technical Specifications  | 5 |
| Safety & Care Information | 6 |
| Warranty Information      | 7 |
| Contact Us                | 8 |

#### Installation



### Key

- 1. Wall & mains supply
- 2. Junction box
- 3. Connection block
- 4. Transformer
- 5. Demister connection

- 6. Heating element
- 7. Backbox
- 8. Screw & wall plug
- 9. Metal hanger
- 10. Mirror

The Ablaze Premium Back-Lit Mirror models in this guide are designed to be concealed wired (hardwired) through the back of the mirror and wired into a separate switch, timer or PIR movement sensor. The Ablaze Premium Back-Lit Mirrors come in two parts: the mirror with hangers and demister attached and the backbox containing the lights and transformer. There is a small screw used to secure these two parts together during transportation which needs to be removed prior to installation.

#### 1. Switch off the main power


You will be installing the Ablaze Back-Lit Mirror as part of a high voltage mains electrical circuit. To ensure your safety and to protect the mirror, switch off the mains power before you start the installation.

#### 2. Plan the installation and layout

The Ablaze Back-Lit Mirrors require mains supply and a switch/timer/PIR movement sensor. Measure out and install all the necessary items before you install the mirror.

#### 3. Fix the backbox to the wall and connect to main supply

Remove the small fixing screw that holds the backbox to the mirror (see diagram below) and lift the backbox away from the mirror. Place the backbox onto the wall central to your desired final position. Whilst in position mark the four fixing holes. Drill pilot holes in the four marked position and insert wall plugs. Screw the backbox into position. Pull the mains supply cable through the centre of the backbox and wire into the connection block.



Please note the location of the screw will differ for each model

#### 4. Hang the mirror onto the backbox

Connect the Thermomirror demister by slotting the black cable from the back of the mirror into the black cable at the connection block. Line up the mirror above the backbox and gently lower the mirror until the brackets clip into place and you can feel the backbox take the weight of the mirror.

## **Technical Specifications**

| CODE    | LIGHT | SIZE (MM)          | MOUNTING | OUTPUT<br>WATTAGE | DEMISTER<br>INCLUDED |
|---------|-------|--------------------|----------|-------------------|----------------------|
| S500C   | Cool  | W750 x H500 x D45  | H / V    | 39                | Υ                    |
| S759C   | Cool  | W900 x H750 x D45  | H / V    | 55                | Υ                    |
| S900C   | Cool  | W900 x H900 x D45  | N/A      | 68                | Υ                    |
| S1200C  | Cool  | W1200 x H800 x D45 | H / V    | 103               | Υ                    |
| S1500C  | Cool  | W1500 x H800 x D45 | H/V      | 115               | Υ                    |
| SR759C  | Cool  | W900 x H750 x D45  | H / V    | 55                | Υ                    |
| SR1118C | Cool  | W1200 x H800 x D45 | H / V    | 66                | Υ                    |
| RB610W  | Warm  | 610 ø x D45        | N / A    | 18                | N                    |
| RB610C  | Cool  | 610 ø x D45        | N / A    | 18                | Ν                    |
| SS759C  | Cool  | W900 x H750 x D45  | H / V    | 86                | Υ                    |
| SS128C  | Cool  | W1200 x H800 x D45 | H / V    | 108               | Υ                    |
| RS600C  | Cool  | 600 ø x D43        | N / A    | 41                | Υ                    |
| RS600W  | Warm  | 600 ø x D43        | N / A    | 41                | Υ                    |
| RS900C  | Cool  | 900 ø x D43        | N / A    | 79                | Υ                    |
| RS900W  | Warm  | 900 ø x D43        | N / A    | 79                | Υ                    |
| S0500C  | Cool  | W500 x H1000 x D45 | V        | 39                | Υ                    |
| S0500W  | Warm  | W500 x H1000 x D45 | V        | 39                | Υ                    |
| SSC128C | Cool  | W1200 x H800 x D45 | Н        | 39                | Υ                    |

H = Horizontal Mount

V = Vertical Mount

| Supply Voltage | 240V 50Hz |
|----------------|-----------|
| Wiring Method  | Hardwired |
| Warranty       | 3 Years   |
| Ligthning Type | LED       |

#### **Safety & Care Information**

#### **Safety Information**

Ablaze Back-lit Mirrors should be installed and tested by a qualified electrician and in accordance with current local regulations. Where possible the Ablaze Back-Lit Mirror should be screwed into studs or other suitable dry wall anchors, if fixing to hollow walls suitable anchors should be used.

Please read and understand this installation guide in before commencing installation. If you have any queries in regards to installation, please call 1300 368 631.

- Observe and adhere to electrical guidelines when placing your Ablaze Back-Lit Mirror in wet areas
- Ensure any timers or switches used are installed in correct zones according to the IP rating of the timer/switch.

#### **Care Information**

For best results clean mirrors with methylated spirits and water at a rate of 30% methylated spirits and 70% water. Do not use Windex or similar chemical cleaning products. Avoid getting water on the sides or back of the mirror as damage to the silver backing can occur. In coastal areas it is recommended to wipe around the edge of the mirror once a month to avoid salt build up that can cause silver creep.

### **Warranty Registration**

Thermogroup covers all its products with a satisfaction guarantee. In addition, Thermogroup will supply a replacement product where a fault is shown to be caused by manufacture, materials or workmanship providing the goods have been installed correctly and according to installation instructions. This guarantee does not include removal, freight or installation costs. Thermogroup's products come with guarantees that cannot be excluded under Australian Consumer Law and you are entitled to a replacement or refund for a major failure & compensation for any other reasonable foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

To use the warranty, repair or service the customer must provide purchase invoice/receipt, and completed warranty registration form.

If the product develops a fault within the warranty period due to normal wear and tear, Thermogroup at its discretion will recognise whether it's a faulty product or not. If it is impossible or not economical for the manufacturer to repair the product, the manufacturer will replace the faulty product with a new unit of the same model or if there is no stock available of the same model as the product, the manufacturer will replace the product with a new unit of a similar size. No responsibility can be taken for altered dimensions and lining up of existing holes.

The repair service offered within the warranty period only covers the faults and problems as developed from the manufacturer's errors. Any damage caused by improper use or carelessness or incorrect wiring is not covered.

Thermogroup is not responsible for any monetary loss or injuries caused by improper use of this product.



#### Thermogroup

sales@thermogroup.com.au

Phone: 1300 368 632

Technical Helpline: 1300 989 464

www.thermogroup.com.au